



Sentinel SE-1 by LAMAX *Beat*

Quick starting guide

Functions:

Bluetooth **2.1**


Micro SD card 

Micro USB **USB**


FM radio **FM**

Handsfree 

Audio input 

LED flashlight 

Buttons:



Button name	Bluetooth mode	FM radio mode	Audio mode
Power ON / OFF	Switch On/Off to turn on/off the device		
Previous / Volume -	Press – Go to previous track	Press – Go to the previous station	Press – Go to previous track
	Hold – Decrease volume		
Play / Pause	Press – Stop / Start playback	Press – Turn radio On / Off Hold – Search for stations	Press – Stop / Start playback
	Incoming call: Press – Answer call Hold – Reject call		
Next / Volume +	Press – Go to the next track	Press – Go to next station	Press – Go to the next track
	Hold – Increase volume		
Mode	Press – Go to next mode		
Light	Press to turn LED light On/Off		



Overview of voice alerts:

„Power on“ - the device was turned on.

„Bluetooth mode. Pair the device.“ - The unit is in Bluetooth mode and is ready for pairing.

„Paired“ - it has been successful paired with a Bluetooth device.

„Radio“ - the device is in FM radio mode.

„Audio input“ - The unit is in playback mode, ready to play audio recordings from device connected via the 3.5mm jack.

„SD card“ - the device is ready to play tracks from a micro SD card.

Pairing with a Bluetooth device:

Press „M“ to go to Bluetooth mode. Speaker can be paired with a device which supports Bluetooth 2.1 or higher.

In the list of active devices the Sentinel SE-1 is displayed as „SE-1 by LAMAX Beat“.

Once paired, you will hear the notification „Paired“.

If the device is disconnected or the connection is lost you will hear „Bluetooth mode. Pair the device“.

FM radio mode:

Go to mode by pressing „M“.

Connect the micro USB cable, which acts as an antenna.

To find all available stations hold down the „Play / Pause / Handsfree“ button. The device will then scan FM frequencies and store all stations found.

You can then navigate between the stations using the „Previous“ and „Next“.

Playback audio files from the micro SD card:

Enter mode by pressing „M“. Speaker announces „SD card“.

Sentinel SE-1 then plays the MP3s stored on the micro SD card.

Audio input:

After connecting the audio cable to the AUX jack, it plays music from any connected device.

Using handsfree:

To use this feature, you must have the Sentinel SE-1 paired via Bluetooth with a smartphone.

Calls can be accepted / rejected in the standard way on the phone or accepted by pressing the „Handsfree“ button and rejected by holding the „Handsfree“ button.

LED light:

Pressing the „Light“ button turns the LED light on / off.

Charging:

The speaker can be charged using the included micro USB cable from any charger with a USB output or from any computer equipped with a USB output. Charge the device only under supervision.





Full English manual can be downloaded from here:



Die Bedienungsanleitung in Deutsch können Sie von hier runterladen:



Mode d'emploi en français à télécharger ici:



Český manuál ke stažení zde:



Slovenský manuál na stiahnutie tu:



Instrukcja obsługi w języku polskim do pobrania tutaj:



Használati útmutató:



Srpski priručnik možete preuzeti ovde:

<http://beat.lamax-electronics.com/SE1/manuals>

