


Ouick Start Guide



Functions:

Bluetooth 4.0 with a range up to 10 m

- ►II Simple ear-cup controls
- Manage calls using Handsfree
- A High-quality audio experience
- The Audio input for conserving battery power



Pairing

- Make sure that your device (phone, computer or music player) is turned on and keep the devices within one metre of each other.
- 2. Hold down the multi-function ►II button for about 3 seconds until the blue LED starts flashing rapidly.
- 3. On your device activate Bluetooth and search for new Bluetooth devices.
- 4. Select "B-1 by LAMAX Beat" from the list of found devices.
- 5. If required, enter the password "0000" to pair the head-phones.
- When the pairing is successful the blue LED flashes every few seconds.

Switching on

To turn on the headphones, press and hold the multifunction II button. A flashing blue LED indicates that the headphones have been turned on.

Switching off

To turn off the headphones, press and hold the multifunction III button. When the headphones are off, the LED stops flashing.

Playback / Controls

- Press the multi-function I button to start and pause playback.
- Press + to skip to the next track or press and hold to increase volume.

Press — to go to the previous track or press and hold to decrease volume.

Note: When charging, these controls are deactivated.

Call

- To answer an incoming call, press the multi-function I button.
- 2. To end a call, press the same button again.
- 3. To increase or decrease the volume during a call, press and hold + or -.

Charging


To charge the headphones, plug one end of the cable into the micro USB port and the other end into the USB power supply supply with the maximum voltage of 5V, a computer USB port or use an AC adapter designed for USB charging. The red LED indicates it is connected to the power supply and turns off when fully charged. Charge only under supervision.

Using headphones in passive mode

Headphones can be used as standard wired headphones to conserve battery power. Simply plug one end of the 3.5 mm audio cable into the input jack in the bottom of the ear-cup and the other end to your audio device (phone, computer or music player). Connecting the audio cable interrupts the wireless function.

Flexible adjustable headband, together with soft ear cushions adapt to any head shape, allowing comfortable longterm use. Excessive expansion of the headphones bridge can cause its damage.





http://beat.lamax-electronics.com/B1/manuals

Srpski priručnik možete preuzeti ovde:





