



Sounder SO-1 by **LAMAX** *Beat*

Operating Instructions

Functions

Bluetooth 4.1	with a range of up to 10 m
NFC	for quick and easy pairing
Audio Input	for 3.5 mm jack connector
Handsfree	call handling
Micro USB	charging and powerful battery
S-Bass	equalization to enhance bass tones
Water Resistant	IPX4 rating

Controls

On / Off	Hold down  to turn the speaker on or off.
Increase / Decrease Volume	Rotate  clockwise to increase the volume. Rotate anticlockwise to decrease the volume.
Next / Previous Track	Swipe your finger across  from left to right to go to the next track. Swipe your finger across  from right to left to go to the previous track.
Play / Pause	Press  to stop playback. Press again to restart.
Handsfree	Press  to answer an incoming call. Press again to end the call. Press  twice to reject an incoming call.
Equalization	Press S-Bass / Normal button to change the equalization. S-Bass mode enhances the bass, Normal mode sets a balanced sound.

LED Status Indicators

Bluetooth Connection	Blue LED ring flashes when speaker is in pairing mode. Blue LED ring lights up when the speaker is paired.
Connection via Audio Input	Green LED ring lights up when the speaker is connected via the audio input.
Charging	Red LED ring lights up when the speaker is charging. Green LED ring lights up when speaker is charged.

Connecting via Bluetooth

Turn on the speaker by holding . The blue LED ring flashes and the speaker is now in pairing mode. Activate Bluetooth connectivity on your phone or other device. In the Bluetooth settings of your device, search for a new Bluetooth device. Locate "LAMAX Beat SO-1" and pair with it. If you need to enter a pairing passcode code, enter "0000" and confirm. When successfully paired, the track will be heard on the speaker and the LED ring will turn blue.

If your phone or other device uses NFC technology, simply pair the speaker by activating NFC on your device and hold it close to  on the speaker.

Connecting via Audio Input

Speaker can be connected via the audio input, labelled **AUX IN**, using an audio cable with a 3.5 mm jack (cable included). When the speaker is connected, the green LED lights up. The speaker's track controls do not function when connected through the AUX input.

Charging

When the battery level is below 10%, the speaker emits a short beep. To charge the speaker, connect the micro USB cable (included) into the charging port labelled **DC IN**. Connect the other end of the cable to a computer or USB charger. The red LED lights up when charging. The green LED lights up when fully charged. Charging takes approximately 4-5 hours. Do not charge unattended. Use only 5V chargers or USB ports. Higher voltage may damage the device.

Water Resistance

The speaker is resistant to water penetration in accordance with the IPX4 rating. This means it is protected against splashes of water from all angles at the rate of 10 litres per minute and at a pressure of 80 to 100 kN/m² for at least 5 minutes. Do not immerse speaker in water.



Full English manual can be downloaded from here:



Die Bedienungsanleitung in Deutsch können Sie von hier runterladen:



Český manuál ke stažení zde:



Slovenský manuál na stiahnutie tu:



Instrukcja obsługi w języku polskim do pobrania tutaj:



Használati útmutató:

<http://beat.lamax-electronics.com/SO1/manuals>

