



# Street ST-1 by LAMAX *Beat*

---

Quick starting guide

## Functions:


Bluetooth 2.1

Micro SD card 

USB flash **USB**

FM radio **FM**


Handsfree 

Audio input 

## Buttons:

Mode 

Handsfree / Play / Pause 

Previous / Decrease volume 

Next / Increase volume 

Power switch 



Button name	Bluetooth mode	FM radio mode	Audio mode
ON/OFF	Switch the device On / Off		
MODE	Switch between different modes		
Previous / Volume -	Press – Go to previous track	Press – Go to the previous station	Press – Go to previous track
	Hold – Decrease volume		
Next / Volume +	Press – Go to the next track	Press – Go to next station	Press – Go to the next track
	Hold – Increase volume		
HANDSFREE	Press – Stop / Start playback	Press – Turn radio On / Off Hold – Search for stations	Press – Stop / Start playback
	Press – Answer call Hold – Reject call		

---

### **Turning speaker ON/OFF**

To turn speaker on move the power switch to the ON position. A voice alert informs you that the device is on. The speaker is now ready to be connected to a device.

### **Connecting devices to the speaker**

The LAMAX BEAT STREET ST-1 is a multifunctional device that plays music via USB, Bluetooth, 3.5mm jack or the FM radio.

Once the device is connected to the speaker it will automatically switch to that mode and start playing the music files. Press the MODE button to switch between modes.

### **Media mode**

In this mode, the speaker plays through devices connected via USB, micro SDHC and 3.5 mm jack.

### **Radio mode**

After switching to FM radio mode, connect the micro USB cable (which serves as an antenna) and hold HANDSFREE. The speaker scans all frequencies and stores the stations. Pressing NEXT/PREVIOUS switches between these stations.

### **Bluetooth mode**

Connect your mobile phone via Bluetooth. Under the list of active devices the STREET ST-1 is shown as „ST-1 by LAMAX Beat“. Switching between tracks and to Start/Stop playback can be controlled either using a mobile phone or directly on the speaker. In this mode handsfree is activated. Pressing HANDSFREE answers the call, whilst holding HANDSFREE rejects the call.

### **Charging**

The speaker can be charged using the included micro USB cable from any charger with a 5V USB output or from any computers equipped with a 5V USB output. Charge the device only under supervision.

---



Full English manual can be downloaded from here:



Die Bedienungsanleitung in Deutsch können Sie von hier runterladen:



Mode d'emploi en français à télécharger ici:



Český manuál ke stažení zde:



Slovenský manuál na stiahnutie tu:



Instrukcja obsługi w języku polskim do pobrania tutaj:



Használati útmutató:



Srpski priručnik možete preuzeti ovde:

**<http://beat.lamax-electronics.com/ST1/manuals>**

